

## 100KSPS 16-bit Analog Input Board for PCI Express Low Profile

### AI-1664LA-LPE



This product is a Low Profile, PCI Express bus-compliant interface board used to provide an analog signal input function on a PC. This product is multi-channels and multifunction type with 16-bit analog input 64 channels (single-ended input 64 channels or differential input 32 channels), digital I/O and counter function. This product carries buffer memory for 1K of data, allowing sampling to be performed in a variety of trigger / clock conditions.

Windows/Linux driver and full-fledged data logger software "C-LOGGER" is bundled with this product.

Possible to be used as a data recording device for MATLAB and LabVIEW, with dedicated libraries.

\* Specifications, color and design of the products are subject to change without notice.

## Features

### High-precision analog input 64 channels, each 4 channels for digital I/O and counter 1 channel

This product has analog input (10 $\mu$ sec / channel, 16-bit, 64 channels), analog input control signal (LVTTTL level 3 channels), digital I/O (each 4 channels for LVTTTL level) and counter (32-bit, LVTTTL level 1 channel). Capable of setting the analog input at single-ended input 64 channels and differential input 32 channels.

### The start/end of sampling can be controlled by software, comparison of conversion data, an external trigger, etc.

You can select from software, comparison of conversion data or an external trigger to control the start of sampling. You can select from completion of sampling for a specified number of sessions, comparison of conversion data, an external trigger or software to control forcibly the end of sampling. The sampling cycle can be selected from the internal clock or an external clock.

### Equipped with buffer memory (1K data) that can be used in the FIFO or RING format

The analog input / output block contains buffer memory (1K data) that can be used in the FIFO or RING format. This allows for background analog I/O that does not depend on the operation status of the software or PC.

### Digital filter function included to prevent misdetection due to chattering on external signals

A digital filter is included to prevent misdetection due to chattering on the control signal (external trigger input signal, sampling clock input signal, etc.), digital input signal and counter input signal.  
(Except from external clock input signal and counter gate signal)

### Functions and connectors are compatible with PCI compatible board AD16-64(LPCI)LA.

The functions same with PCI compatible board AD16-64(LPCI)LA are provided. In addition, as there is compatibility in terms of connector shape and pin assignments, it is easy to migrate from the existing system.

### Support for both of low-profile and standard PCI slots (interchangeable with a bundled bracket)

This product has each bracket for both low-profile size slot and standard size slot. If you wish to mount this product in a standard size slot, replace this with the standard size bracket.

### Software-based calibration function

Calibration of analog input can be all performed by software. Apart from the adjustment information prepared before shipment, additional adjustment information can be stored according to the use environment.

### Data logger software, Windows/Linux compatible driver libraries are attached.

Using the bundled data logger software "C-LOGGER" allows you to display recorded signal data in graphs, save files without any special program. In addition, the driver library API-PAC(W32) which makes it possible to create applications of Windows/Linux is provided.

### MATLAB and LabVIEW is supported by a plug-in of dedicated library VI-DAQ.

Using the dedicated library MATLAB and VI-DAQ makes it possible to make a LabVIEW application.


## Specification

Item	Specification
<b>Analog input</b>	
Isolated specification	Un-Isolated
Input type	Single-Ended Input or Differential Input (by software)
Input channel	64ch (single-ended input), 32ch (differential input)
Input range	Bipolar $\pm 10V$
Absolute max. input voltage	$\pm 20V$
Input impedance	1M $\Omega$ or more
Resolution	16Bit
Non-Linearity error *1 *2	$\pm 5LSB$
Conversion speed	10 $\mu$ sec/ch
Buffer memory	1k Word
Conversion start trigger	Software / external trigger
Conversion stop trigger	Number of sampling times / external trigger / software
External start signal	LVTTL-level (Rising or falling edge can be selected by software) Digital filter (select 1 $\mu$ sec by software)
External stop signal	LVTTL-level (Rising or falling edge can be selected by software) Digital filter (select 1 $\mu$ sec by software)
External clock signal	LVTTL-level (Rising or falling edge can be selected by software) Digital filter (select 1 $\mu$ sec by software)
<b>Digital I/O</b>	
Number of input channels	Un-Isolated input 4 channels (LVTTL-level positive logic)
Number of output channels	Un-Isolated output 4 channels (LVTTL-level positive logic)
<b>Counter</b>	
Number of channels	1ch
Counting system	Up count
Max. count	FFFFFFFFh (Binary data, 32bit)
Number of external inputs	2 LVTTL (Gate/Up) Gate (High level), Up (Rising edge)
Number of external outputs	LVTTL Count match output (positive logic, pulse output)
Response frequency	10MHz (Max.)
<b>Common</b>	
I/O address	64 ports boundary
Interrupt level	Errors and various factors, One interrupt request line as INTA
Connector	68 pin 0.8mm pitch connector HDRA-E68W1LFD1-SL [HONDA] or equivalent to it
Power consumption	3.3VDC 620mA (Max.)
Operating condition	0 - 50°C, 10 - 90%RH (No condensation)
Bus specification	PCI Express Base Specification Rev. 1.0a x1
Dimension (mm)	121.69(L) x 67.90(H)
Weight	90g
Standard	VCCI Class A, CE Marking (EMC Directive Class A, RoHS Directive), UKCA

\*1 The non-linearity error means an error of approximately 0.1% occurs over the maximum range at 0°C and 50°C ambient temperature.

\*2 At the time of the source use of a signal which built in the high-speed operational amplifier.

## Board Dimensions



## Support Software

### Windows version of analog I/O driver API-AIO(WDM)

The API-AIO(WDM) is the Windows version driver library software that provides products in the form of Win32 API functions (DLL). Various sample programs such as Visual Basic and Visual C++, etc and diagnostic program \*1 useful for checking operation is provided.

For more details on the supported OS, applicable language and new information, please visit the CONTEC's Web site.

### Linux version of analog I/O driver API-AIO(LNX)

The API-AIO(LNX) is the Linux version driver software which provides device drivers (modules) by shared library and kernel version. Various sample programs of gcc are provided.

For more details on the supported OS, applicable language and new information, please visit the CONTEC's Web site..

### Data Logger Software C-LOGGER

[Stored on the bundled disk driver library API-PAC(W32)]

C-LOGGER is a data logger software program compatible with our analog I/O products. This program enables the graph display of recorded signal data, zoom observation, file saving, and dynamic transfer to the spreadsheet software "Excel". No troublesome programming is required.

For more details on the supported OS, applicable language and new information, please visit the CONTEC's Web site.

### Data Acquisition library for MATLAB ML-DAQ

This is the library software which allows you to use our analog I/O device products on MATLAB by the MathWorks. Each function is offered in accordance with the interface which is integrated in MATLAB's Data Acquisition Toolbox.

For more details on the supported OS, applicable language and new information, please visit the CONTEC's Web site.

### Data acquisition VI library for LabVIEW VI-DAQ

This is a VI library to use in National Instruments LabVIEW.

VI-DAQ is created with a function form similar to that of LabVIEW's Data Acquisition VI, allowing you to use various devices without complicated settings.

See <http://www.contec.com/vidaq/> for details and download of VI-DAQ.

## Cable & Connector

### Cable(Optional)

Shielded cables with two-ended connector  
for 68-pin half-pitch connector : PCB68PS-0.5P (0.5m)  
: PCB68PS-1.5P (1.5m)

Shielded cables with single-ended connector  
for 68-pin half-pitch connector : PCA68PS-0.5P (0.5m)  
: PCA68PS-1.5P (1.5m)

68/96-pin conversion shielded cable  
for analog input/output : ADC-68M/96F (0.5m)

\* Two sets of cables are required to use both connector CNA and CNB.

## Accessories

### Accessories (Option)

Screw Terminal (M3x 96P) : DTP-64A \*1\*3  
Screw Terminal (M3 x 68P) : EPD-68A \*2\*3\*4  
Screw Terminal (M3 x 96P) : EPD-96A \*1\*3\*4  
Screw Terminal (M3.5 x 96P) : EPD-96 \*1\*3  
BNC Terminal Unit (analog input 32ch) : ATP-32F \*1\*3  
BNC Terminal Unit (analog input 8ch) : ATP-8 \*1\*3\*5


- \*1 ADC-68M/96F optional cable is required separately.  
\*2 PCB68PS-0.5P or PCB68PS-1.5P optional cable is required separately.  
\*3 Two sets of cables are required to use both connector CNA and CNB.  
\*4 "Spring-up" type terminal is used to prevent terminal screws from falling off.  
\*5 Can be used in CNA channels 0 - 7 or CNB channels 32 - 39.  
\* For details on the range channels available to each terminal panel, see Page 3 "Connecting example of option".  
\* Check the CONTEC's Web site for more information on these options.

## Packing List

Board [AI-1664LA-LPE] ... 1  
First step guide ... 1  
Disk \*1 [API-PAC(W32)] ... 1  
Standard-sized bracket ... 1  
Serial number label ... 1  
Warranty Certificate ... 1

\*1 The Disk contains the driver software and User's Guide.


## Block Diagram



## How to connect the connectors


### Connector shape

The optional connector cable (PCB68PS-\*\*P, ADC-68M/96F or PCA68PS-\*\*P) is used to connect the board to external devices. The cable is used together with a terminal block to connect external devices. Two sets of cables are required depending on the number of channels used.



\* Please refer to Page 3 for more information on the supported cable and accessories.

### Connecting example of option



### Each terminal block accepts the following ranges of channels.

	Connector at board side connection destination	Analog input		Analog input control signal *1	Digital input Digital output	Counter I/O *2
		Single-ended input	Differential input			
EPD-96A	Only CNA is used.	channel 0 - 31	channel 0 - 15	O	O	O
EPD-96	Only CNB is used.	channel 32 - 63	channel 16 - 31	--	--	--
EPD-68A	CNA/B is used *3	channel 0 - 63	channel 0 - 31	O *4	O *4	O *4
DTP-64	Only CNA is used.	channel 0 - 31	--	O	O	O
ATP-32F	Only CNB is used.	channel 32 - 63	--	--	--	--
	CNA/B is used *3	channel 0 - 63	--	O *4	O *4	O *4
ATP-8	Only CNA is used.	channel 0 - 7	--	O	O	O
	Only CNB is used.	channel 32 - 39 *5	--	--	--	--
	CNA/B is used *3	channel 0 - 7, 32 - 39 *5	--	O *4	O *4	O *4

\*1: AI External Start Trigger Input, AI External Stop Trigger Input, AI External Clock Trigger Input

\*2: Counter Gate Control Input, Counter Up Clock Input, Counter Output

\*3: Two sets of terminal blocks and optional cables are required each.

\*4: Make wiring on the CAN side.

\*5: Two or more only of channel 32 - 39 sampling cannot be done.

## Connector Pin Assignment

### Single-Ended Input (CNA, CNB)

N.C.	86	34 N.C.	N.C.	1	36 Analog Ground (for AI)
N.C.	87	33 N.C.	N.C.	2	37 Analog Ground (for AI)
N.C.	88	32 N.C.	Analog Ground (for AI)	3	38 Analog Input 16
N.C.	89	31 N.C.	Analog Input 00	4	39 Analog Input 17
N.C.	90	30 N.C.	Analog Input 01	5	40 Analog Input 18
N.C.	91	29 N.C.	Analog Input 02	6	41 Analog Input 19
N.C.	92	28 N.C.	Analog Input 03	7	42 Analog Input 20
Digital Ground	93	27 N.C.	Analog Ground (for AI)	8	43 Analog Input 21
N.C.	94	26 N.C.	Analog Input 04	9	44 Analog Input 22
N.C.	95	25 N.C.	Analog Input 05	10	45 Analog Input 23
Digital Ground	96	24 N.C.	Analog Input 06	11	46 Analog Input 24
N.C.	97	23 N.C.	Analog Input 07	12	47 Analog Input 25
Analog Input 63	98	22 Analog Input 47	Analog Ground (for AI)	13	48 Analog Input 26
Analog Input 62	99	21 Analog Input 48	Analog Input 08	14	49 Analog Input 27
Analog Input 61	100	20 Analog Input 49	Analog Input 09	15	50 Analog Input 28
Analog Input 60	101	19 Analog Input 44	Analog Input 10	16	51 Analog Input 29
Analog Ground (for AI)	102	18 Analog Ground (for AI)	Analog Input 11	17	52 Analog Input 30
Analog Input 59	103	17 Analog Input 43	Analog Ground (for AI)	18	53 Analog Input 31
Analog Input 58	104	16 Analog Input 42	Analog Input 12	19	54 Analog Input 32
Analog Input 57	105	15 Analog Input 41	Analog Input 13	20	55 Analog Input 33
Analog Input 56	106	14 Analog Input 40	Analog Input 14	21	56 Analog Input 34
Analog Ground (for AI)	107	13 Analog Ground (for AI)	Analog Input 15	22	57 Analog Input 35
Analog Input 55	108	12 Analog Input 39	Input Control External Sampling Start Trigger Input	23	58 Analog Input 36
Analog Input 54	109	11 Analog Input 38	Input Control External Sampling Stop Trigger Input	24	59 Analog Input 37
Analog Input 53	110	10 Analog Input 37	N.C.	25	60 Analog Input 38
Analog Input 52	111	9 Analog Input 36	N.C.	26	61 Analog Input 39
Analog Ground (for AI)	112	8 Analog Ground (for AI)	N.C.	27	62 Analog Input 40
Analog Input 51	113	7 Analog Input 35	N.C.	28	63 Analog Input 41
Analog Input 50	114	6 Analog Input 34	Digital Input 00	29	64 Analog Input 42
Analog Input 49	115	5 Analog Input 33	Digital Input 01	30	65 Analog Input 43
Analog Input 48	116	4 Analog Input 32	Digital Output 00	31	66 Analog Input 44
Analog Ground (for AI)	117	3 Analog Ground (for AI)	Digital Output 02	32	67 Analog Input 45
Analog Ground (for AI)	118	2 N.C.	Counter Gate Control Input	33	68 Analog Input 46
Analog Ground (for AI)	119	1 N.C.	Counter Clock Input	34	69 Analog Input 47

Analog Input00 - Analog Input63	Analog input signal. The numbers correspond to channel numbers.
Analog Ground	Common analog ground for analog input signals.
AI External Start Trigger Input	External trigger input for starting analog input sampling.
AI External Stop Trigger Input	External trigger input for stopping analog input sampling.
AI External Sampling Clock Input	External sampling clock input for analog input.
Digital Input00 - Digital Input03	Digital input signal.
Digital Output00 - Digital Output03	Digital output signal.
Counter Gate Control Input	Gate control input signal for counter.
Counter Up Clock Input	Count-up clock input signal for counter.
Counter Output	Count output signal.
Digital Ground	Common digital ground for digital I/O signals, external trigger inputs, external sampling clock inputs, and counter I/O signals.
Reserved	Reserved pin
N.C.	No connection to this pin.

### CAUTION

Do not connect any of the outputs and power outputs to the analog or digital ground. Neither connect outputs to each other. Doing either can result in a fault.

If analog and digital ground are shorted together, noise on the digital signals may affect the analog signals. Accordingly, analog and digital ground should be separated.

Leave "Reserved" pins unconnected. Connecting these pins may cause a fault in the board.

### Single-Ended Input (ADC-68M/96F)

N.C.	B01	A01 N.C.	N.C.	A48	B48 N.C.
N.C.	B02	A02 N.C.	Analog Ground (for AI)	A47	B47 N.C.
N.C.	B03	A03 N.C.	N.C.	A46	B46 N.C.
N.C.	B04	A04 N.C.	Analog Ground (for AI)	A45	B45 N.C.
N.C.	B05	A05 N.C.	Analog Input 00	A44	B44 Analog Input 08
N.C.	B06	A06 N.C.	Analog Input 16	A43	B43 Analog Input 24
N.C.	B07	A07 N.C.	Analog Input 01	A42	B42 Analog Input 09
Digital Ground	B08	A08 Digital Ground	Analog Input 17	A41	B41 Analog Input 25
N.C.	B09	A09 N.C.	N.C.	A40	B40 N.C.
N.C.	B10	A10 N.C.	N.C.	A39	B39 N.C.
N.C.	B11	A11 N.C.	Analog Input 02	A38	B38 Analog Input 10
N.C.	B12	A12 N.C.	Analog Input 18	A37	B37 Analog Input 26
N.C.	B13	A13 N.C.	Analog Input 03	A36	B36 Analog Input 11
N.C.	B14	A14 N.C.	Analog Input 19	A35	B35 Analog Input 27
N.C.	B15	A15 N.C.	Analog Ground (for AI)	A34	B34 Analog Ground (for AI)
N.C.	B16	A16 N.C.	N.C.	A33	B33 Analog Ground (for AI)
N.C.	B17	A17 N.C.	Analog Input 04	A32	B32 Analog Input 12
N.C.	B18	A18 N.C.	Analog Input 20	A31	B31 Analog Input 28
N.C.	B19	A19 N.C.	Analog Input 05	A30	B30 Analog Input 13
N.C.	B20	A20 N.C.	Analog Input 21	A29	B29 Analog Input 29
Analog Ground (for AI)	B21	A21 Analog Ground (for AI)	N.C.	A28	B28 N.C.
Analog Ground (for AI)	B22	A22 Analog Ground (for AI)	N.C.	A27	B27 N.C.
Analog Input 63	B23	A23 Analog Input 55	Analog Input 06	A26	B26 Analog Input 14
Analog Input 62	B24	A24 Analog Input 59	Analog Input 22	A25	B25 Analog Input 30
Analog Input 61	B25	A25 Analog Input 54	Analog Input 07	A24	B24 Analog Input 15
Analog Input 60	B26	A26 Analog Input 38	Analog Input 23	A23	B23 Analog Input 31
Analog Input 59	B27	A27 N.C.	Analog Ground (for AI)	A22	B22 Analog Ground (for AI)
N.C.	B28	A28 N.C.	Analog Ground (for AI)	A21	B21 Analog Ground (for AI)
Analog Input 61	B29	A29 Analog Input 53	N.C.	A20	B20 N.C.
Analog Input 60	B30	A30 Analog Input 37	N.C.	A19	B19 N.C.
Analog Input 59	B31	A31 Analog Input 52	Digital Input 00	A18	B18 Digital Output 00
Analog Input 58	B32	A32 Analog Input 36	Digital Input 01	A17	B17 Digital Output 01
Analog Ground (for AI)	B33	A33 Analog Ground (for AI)	Digital Input 02	A16	B16 Digital Output 02
Analog Ground (for AI)	B34	A34 Analog Ground (for AI)	Digital Input 03	A15	B15 Digital Output 03
Analog Input 59	B35	A35 Analog Input 51	N.C.	A14	B14 N.C.
Analog Input 43	B36	A36 Analog Input 35	N.C.	A13	B13 N.C.
Analog Input 42	B37	A37 Analog Input 50	N.C.	A12	B12 N.C.
N.C.	B38	A38 Analog Input 54	N.C.	A11	B11 N.C.
N.C.	B39	A39 N.C.	N.C.	A10	B10 N.C.
N.C.	B40	A40 N.C.	N.C.	A09	B09 N.C.
Analog Input 57	B41	A41 Analog Input 48	Digital Ground	A08	B08 Digital Ground
Analog Input 41	B42	A42 Analog Input 53	Input Control External Sampling Clock Input	A07	B07 N.C.
Analog Input 56	B43	A43 Analog Input 48	Input Control External Sampling Stop Trigger Input	A06	B06 N.C.
Analog Input 40	B44	A44 Analog Input 32	Input Control External Sampling Start Trigger Input	A05	B05 N.C.
N.C.	B45	A45 Analog Ground (for AI)	Counter Clock Input	A04	B04 N.C.
N.C.	B46	A46 N.C.	Reserved (Counter Input)	A03	B03 N.C.
N.C.	B47	A47 Ground (for AI)	Counter Gate Control Input	A02	B02 N.C.
N.C.	B48	A48 N.C.	Counter Count-up Pulse Output	A01	B01 N.C.

[ ] shows the pin No. specified by HONDA TSUSHIN KOGYO CO., LTD.

Analog Input00 - Analog Input63	Analog input signal. The numbers correspond to channel numbers.
Analog Ground	Common analog ground for analog input signals.
AI External Start Trigger Input	External trigger input for starting analog input sampling.
AI External Stop Trigger Input	External trigger input for stopping analog input sampling.
AI External Sampling Clock Input	External sampling clock input for analog input.
Digital Input00 - Digital Input03	Digital input signal.
Digital Output00 - Digital Output03	Digital output signal.
Counter Gate Control Input	Gate control input signal for counter.
Counter Up Clock Input	Count-up clock input signal for counter.
Counter Output	Count output signal.
Digital Ground	Common digital ground for digital I/O signals, external trigger inputs, external sampling clock inputs, and counter I/O signals.
Reserved	Reserved pin
N.C.	No connection to this pin.

### CAUTION

Do not connect any of the outputs and power outputs to the analog or digital ground. Neither connect outputs to each other. Doing either can result in a fault.

If analog and digital ground are shorted together, noise on the digital signals may affect the analog signals. Accordingly, analog and digital ground should be separated.

Leave "Reserved" pins unconnected. Connecting these pins may cause a fault in the board.

## Differential Input (CNA, CNB)

N.C.	86	34	N.C.	N.C.	1	34	Analog Ground ( for AI )	34	Analog Ground ( for AI )
N.C.	87	33	N.C.	N.C.	2	33	Analog Ground ( for AI )	33	Analog Ground ( for AI )
N.C.	88	32	N.C.	Analog Ground ( for AI )	3	32	Analog Input 00(-)	32	Analog Input 00(-)
N.C.	89	31	N.C.	Analog Input 01(+)	4	31	Analog Input 01(+)	31	Analog Input 01(+)
N.C.	90	30	N.C.	Analog Input 02(+)	5	30	Analog Input 02(+)	30	Analog Input 02(+)
N.C.	91	29	N.C.	Analog Input 03(-)	6	29	Analog Input 03(-)	29	Analog Input 03(-)
Digital Ground	92	28	N.C.	Analog Ground ( for AI )	7	28	Analog Ground ( for AI )	28	Analog Ground ( for AI )
N.C.	93	27	N.C.	Analog Input 04(+)	8	27	Analog Input 04(+)	27	Analog Input 04(+)
N.C.	94	26	N.C.	Analog Input 05(+)	9	26	Analog Input 05(+)	26	Analog Input 05(+)
Digital Ground	95	25	N.C.	Analog Input 06(+)	10	25	Analog Input 06(+)	25	Analog Input 06(+)
N.C.	96	24	N.C.	Analog Input 07(-)	11	24	Analog Input 07(-)	24	Analog Input 07(-)
N.C.	97	23	N.C.	Analog Ground ( for AI )	12	23	Analog Ground ( for AI )	23	Analog Ground ( for AI )
Analog Input 31(-)	98	22	Analog Input 31(+)	Analog Ground ( for AI )	13	22	Analog Input 31(+)	22	Analog Input 31(+)
Analog Input 30(-)	99	21	Analog Input 30(+)	Analog Input 08(+)	14	21	Analog Input 08(+)	21	Analog Input 08(+)
Analog Input 29(-)	100	20	Analog Input 29(+)	Analog Input 09(+)	15	20	Analog Input 09(+)	20	Analog Input 09(+)
Analog Input 28(-)	101	19	Analog Input 28(+)	Analog Input 10(+)	16	19	Analog Input 10(+)	19	Analog Input 10(+)
Analog Ground ( for AI )	102	18	Analog Input 27(-)	Analog Input 11(+)	17	18	Analog Input 11(+)	18	Analog Input 11(+)
Analog Input 27(-)	103	17	Analog Input 27(+)	Analog Ground ( for AI )	18	17	Analog Ground ( for AI )	17	Analog Ground ( for AI )
Analog Input 26(-)	104	16	Analog Input 26(+)	Analog Input 12(+)	19	16	Analog Input 12(+)	16	Analog Input 12(+)
Analog Input 25(-)	105	15	Analog Input 25(+)	Analog Input 13(+)	20	15	Analog Input 13(+)	15	Analog Input 13(+)
Analog Ground ( for AI )	106	14	Analog Input 24(-)	Analog Input 14(+)	21	14	Analog Input 14(+)	14	Analog Input 14(+)
Analog Input 24(-)	107	13	Analog Ground ( for AI )	Analog Input 15(+)	22	13	Analog Input 15(+)	13	Analog Input 15(+)
Analog Input 23(-)	108	12	Analog Input 23(+)	Input Control External Sampling Start Trigger Input	23	12	Input Control External Sampling Start Trigger Input	12	Input Control External Sampling Start Trigger Input
Analog Input 22(-)	109	11	Analog Input 22(+)	Input Control External Sampling Clock Input	24	11	Input Control External Sampling Clock Input	11	Input Control External Sampling Clock Input
Analog Input 21(-)	110	10	Analog Input 21(+)	N.C.	25	10	N.C.	10	N.C.
Analog Input 20(-)	111	9	Analog Input 20(+)	N.C.	26	9	N.C.	9	N.C.
Analog Ground ( for AI )	112	8	N.C.	N.C.	27	8	N.C.	8	N.C.
Analog Input 19(-)	113	7	Analog Input 19(+)	N.C.	28	7	N.C.	7	N.C.
Analog Input 18(-)	114	6	Analog Input 18(+)	Digital Input 00	29	6	Digital Input 00	6	Digital Input 00
Analog Input 17(-)	115	5	Analog Input 17(+)	Digital Input 01	30	5	Digital Input 01	5	Digital Input 01
Analog Input 16(-)	116	4	Analog Input 16(+)	Digital Input 02	31	4	Digital Input 02	4	Digital Input 02
Analog Ground ( for AI )	117	3	Analog Ground ( for AI )	Digital Input 03	32	3	Digital Input 03	3	Digital Input 03
Analog Input 15(-)	118	2	N.C.	Counter Gate Control Input	33	2	Counter Gate Control Input	2	Counter Gate Control Input
Analog Ground ( for AI )	119	1	N.C.	Counter Clock Input	34	1	Counter Clock Input	1	Counter Clock Input
Analog Ground ( for AI )	120			Counter Clock Input	35				

Analog Input00 - Analog Input31	Analog input signal. The numbers correspond to channel numbers.
Analog Ground	Common analog ground for analog input signals.
AI External Start Trigger Input	External trigger input for starting analog input sampling.
AI External Stop Trigger Input	External trigger input for stopping analog input sampling.
AI External Sampling Clock Input	External sampling clock input for analog input.
Digital Input00 - Digital Input03	Digital input signal.
Digital Output00 - Digital Output03	Digital output signal.
Counter Gate Control Input	Gate control input signal for counter.
Counter Up Clock Input	Count-up clock input signal for counter.
Counter Output	Count output signal.
Digital Ground	Common digital ground for digital I/O signals, external trigger inputs, external sampling clock inputs, and counter I/O signals.
Reserved	Reserved pin
N.C.	No connection to this pin.

### CAUTION

Do not connect any of the outputs and power outputs to the analog or digital ground. Neither connect outputs to each other. Doing either can result in a fault.

If analog and digital ground are shorted together, noise on the digital signals may affect the analog signals. Accordingly, analog and digital ground should be separated. Leave "Reserved" pins unconnected. Connecting these pins may cause a fault in the board.

## Differential Input (ADC-68M/96F)

N.C.	801	A01	N.C.	N.C.	A48	801	N.C.	801	N.C.
N.C.	802	A02	N.C.	Analog Ground ( for AI )	A47	802	N.C.	802	N.C.
N.C.	803	A03	N.C.	N.C.	A46	803	N.C.	803	N.C.
N.C.	804	A04	N.C.	Analog Ground ( for AI )	A45	804	N.C.	804	N.C.
N.C.	805	A05	N.C.	Analog Input 00(+)	A44	805	N.C.	805	N.C.
N.C.	806	A06	N.C.	Analog Input 01(+)	A43	806	N.C.	806	N.C.
N.C.	807	A07	N.C.	Analog Input 02(+)	A42	807	N.C.	807	N.C.
Digital Ground	808	A08	Digital Ground	Analog Input 03(+)	A41	808	Digital Ground	808	Digital Ground
N.C.	809	A09	N.C.	N.C.	A40	809	N.C.	809	N.C.
N.C.	810	A10	N.C.	N.C.	A39	810	N.C.	810	N.C.
N.C.	811	A11	N.C.	Analog Input 04(+)	A38	811	N.C.	811	N.C.
N.C.	812	A12	N.C.	Analog Input 05(+)	A37	812	N.C.	812	N.C.
N.C.	813	A13	N.C.	Analog Input 06(+)	A36	813	N.C.	813	N.C.
N.C.	814	A14	N.C.	Analog Input 07(+)	A35	814	N.C.	814	N.C.
N.C.	815	A15	N.C.	Analog Ground ( for AI )	A34	815	N.C.	815	N.C.
N.C.	816	A16	N.C.	Analog Ground ( for AI )	A33	816	N.C.	816	N.C.
N.C.	817	A17	N.C.	Analog Input 08(+)	A32	817	N.C.	817	N.C.
N.C.	818	A18	N.C.	Analog Input 09(+)	A31	818	N.C.	818	N.C.
N.C.	819	A19	N.C.	Analog Input 10(+)	A30	819	N.C.	819	N.C.
N.C.	820	A20	N.C.	Analog Input 11(+)	A29	820	N.C.	820	N.C.
Analog Ground ( for AI )	821	A21	Analog Ground ( for AI )	N.C.	A28	821	Analog Ground ( for AI )	821	Analog Ground ( for AI )
Analog Ground ( for AI )	822	A22	Analog Ground ( for AI )	N.C.	A27	822	Analog Ground ( for AI )	822	Analog Ground ( for AI )
Analog Input 31(-)	823	A23	Analog Input 31(+)	Analog Input 12(+)	A26	823	Analog Input 31(+)	823	Analog Input 31(+)
Analog Input 30(-)	824	A24	Analog Input 30(+)	Analog Input 13(+)	A25	824	Analog Input 30(+)	824	Analog Input 30(+)
N.C.	825	A25	N.C.	Analog Input 14(+)	A24	825	N.C.	825	N.C.
N.C.	826	A26	N.C.	Analog Input 15(+)	A23	826	N.C.	826	N.C.
N.C.	827	A27	N.C.	Analog Input 16(+)	A22	827	N.C.	827	N.C.
N.C.	828	A28	N.C.	Analog Ground ( for AI )	A21	828	N.C.	828	N.C.
N.C.	829	A29	Analog Input 21(-)	Analog Ground ( for AI )	A20	829	Analog Input 21(-)	829	Analog Input 21(-)
Analog Input 29(-)	830	A30	Analog Input 29(+)	N.C.	A19	830	Analog Input 29(+)	830	Analog Input 29(+)
Analog Input 28(-)	831	A31	Analog Input 28(+)	Digital Input 00	A18	831	Analog Input 28(+)	831	Analog Input 28(+)
Analog Input 27(-)	832	A32	Analog Input 27(+)	Digital Input 01	A17	832	Analog Input 27(+)	832	Analog Input 27(+)
Analog Ground ( for AI )	833	A33	Analog Ground ( for AI )	Digital Input 02	A16	833	Analog Ground ( for AI )	833	Analog Ground ( for AI )
Analog Ground ( for AI )	834	A34	Analog Ground ( for AI )	Digital Input 03	A15	834	Analog Ground ( for AI )	834	Analog Ground ( for AI )
Analog Input 27(-)	835	A35	Analog Input 27(+)	N.C.	A14	835	Analog Input 27(+)	835	Analog Input 27(+)
Analog Input 26(-)	836	A36	Analog Input 26(+)	N.C.	A13	836	Analog Input 26(+)	836	Analog Input 26(+)
Analog Input 25(-)	837	A37	Analog Input 25(+)	N.C.	A12	837	Analog Input 25(+)	837	Analog Input 25(+)
Analog Input 24(-)	838	A38	Analog Input 24(+)	N.C.	A11	838	Analog Input 24(+)	838	Analog Input 24(+)
N.C.	839	A39	N.C.	N.C.	A10	839	N.C.	839	N.C.
N.C.	840	A40	N.C.	N.C.	A09	840	N.C.	840	N.C.
Analog Input 29(-)	841	A41	Analog Input 29(+)	Digital Ground	A08	841	Analog Input 29(+)	841	Analog Input 29(+)
Analog Input 28(-)	842	A42	Analog Input 28(+)	Input Control External Sampling Start Trigger Input	A07	842	Analog Input 28(+)	842	Analog Input 28(+)
Analog Input 24(-)	843	A43	Analog Input 24(+)	Input Control External Sampling Stop Trigger Input	A06	843	Analog Input 24(+)	843	Analog Input 24(+)
Analog Input 24(+)	844	A44	Analog Input 16(+)	Input Control External Sampling Start Trigger Input	A05	844	Analog Input 16(+)	844	Analog Input 16(+)
N.C.	845	A45	Analog Ground ( for AI )	Counter Clock Input	A04	845	Analog Ground ( for AI )	845	Analog Ground ( for AI )
N.C.	846	A46	N.C.	Reserved ( Counter Input )	A03	846	N.C.	846	N.C.
N.C.	847	A47	Analog Ground ( for AI )	Counter Gate Control Input	A02	847	Analog Ground ( for AI )	847	Analog Ground ( for AI )
N.C.	848	A48	N.C.	Counter Count-up Pulse Output	A01	848	N.C.	848	N.C.

[ ] shows the pin No. specified by HONDA TSUSHIN KOGYO CO., LTD.

Analog Input00 - Analog Input31	Analog input signal. The numbers correspond to channel numbers.
Analog Ground	Common analog ground for analog input signals.
AI External Start Trigger Input	External trigger input for starting analog input sampling.
AI External Stop Trigger Input	External trigger input for stopping analog input sampling.
AI External Sampling Clock Input	External sampling clock input for analog input.
Digital Input00 - Digital Input03	Digital input signal.
Digital Output00 - Digital Output03	Digital output signal.
Counter Gate Control Input	Gate control input signal for counter.
Counter Up Clock Input	Count-up clock input signal for counter.
Counter Output	Count output signal.
Digital Ground	Common digital ground for digital I/O signals, external trigger inputs, external sampling clock inputs, and counter I/O signals.
Reserved	Reserved pin
N.C.	No connection to this pin.

### CAUTION

Do not connect any of the outputs and power outputs to the analog or digital ground. Neither connect outputs to each other. Doing either can result in a fault.

If analog and digital ground are shorted together, noise on the digital signals may affect the analog signals. Accordingly, analog and digital ground should be separated. Leave "Reserved" pins unconnected. Connecting these pins may cause a fault in the board.




## Analog Input Signal Connection

### Single-ended Input


The following figure shows an example of flat cable connection. Connect separate signal and ground wires for each analog input channel on CNA/B.

#### Single-ended Input Connection (Flat Cable)



The following figure shows an example of shield cable connection. Use shielded cable if the distance between the signal source and board is long or if you want to provide better protection from noise. For each analog input channel on CNA/B, connect the core wire to the signal line and connect the shielding to ground.

#### Single-ended Input Connection (Shield Cable)



#### CAUTION

If the signal source contains over 1MHz signals, the signal may effect the cross-talk noise between channels.

If the board and the signal source receive noise or the distance between the board and the signal source is too long, data may not be input properly.

An input analog signal should not exceed the maximum input voltage (relate to the board analog ground). If it exceeds the maximum voltage, the board may be damaged.

Connect all the unused analog input channels to analog ground.

The signal connected to an input pin may fluctuate after switching of the multiplexer. If this occurs, shorten the cable between the signal source and the analog input pin or insert a high-speed amplifier as a buffer between the two to reduce the fluctuation.

In the channel switching, the multiplexer does the electrical charge and discharge on the internal capacitor according to the signal voltage. Therefore, the voltage from the previous switching state may go into the next channel. It might cause the error of the signal source action. If this occurs, insert a high-speed amplifier as a buffer between the signal source and the analog input pin to reduce the fluctuation.


An input pin may fail to obtain input data normally when the signal source connected to the pin has high impedance. If this is the case, change the signal source to one with lower output impedance or insert a high-speed amplifier buffer between the signal source and the analog input pin to reduce the effect.

### Differential Input

The following figure shows an example of flat cable connection.


For each analog input channel on CNA/B, connect the "+" input to the signal and connect the "-" input to the signal source ground. Also connect the analog ground on the board to the signal source ground.

#### Differential Input Connection (Flat Cable)



The following figure shows an example of shielded cable connection. Use shielded cable if the distance between the signal source and board is long or if you want to provide better protection from noise. For each analog input channel on CNA/B, connect the "+" input to the signal and connect the "-" input to the signal source ground. Also connect the analog ground on the board and the signal source ground to the shielding.

#### Differential Input Connection (Shield Cable)



#### CAUTION

If the signal source contains over 1MHz signals, the signal may effect the cross-talk noise between channels.

When the analog ground is not connected, the conversion data is not determined.

If the board and the signal source receive noise or the distance between the board and the signal source is too long, data may not be input properly.

An input analog signal should not exceed the maximum input voltage (relate to the board analog ground). If it exceeds the maximum voltage, the board may be damaged.

Connect all the unused analog input channels to analog ground.

The signal connected to an input pin may fluctuate after switching of the multiplexer. If this occurs, shorten the cable between the signal source and the analog input pin or insert a high-speed amplifier as a buffer between the two to reduce the fluctuation.


In the channel switching, the multiplexer does the electrical charge and discharge on the internal capacitor according to the signal voltage. Therefore, the voltage from the previous switching state may go into the next channel. It might cause the error of the signal source action. If this occurs, insert a high-speed amplifier as a buffer between the signal source and the analog input pin to reduce the fluctuation.

An input pin may fail to obtain input data normally when the signal source connected to the pin has high impedance. If this is the case, change the signal source to one with lower output impedance or insert a high-speed amplifier buffer between the signal source and the analog input pin to reduce the effect.


## Digital I/O signals, Counter signals and Control signals Connection

The following sections show examples of how to connect digital I/O signals, counter I/O signals, and other control I/O signals (external trigger input signals, sampling clock input signals, etc.). All the digital I/O signals and control signals are TTL level signals.

### Digital Input Connection



### Digital Output Connection



### Counter input signal control

The counter gate control input (see Connector Pin Assignment in Page4) enables or disables the external clock input to the counter. You can use this function to control the external clock input to the counter. The external clock input to the counter is enabled when the input is "High" and disabled when the input is "Low". As the pin has an internal pull-up on the board (or card), the default if not connected is "High". As a result, the external clock for the counter is enabled if this pin is not connected.

### CAUTION

Do not short the output signals to analog ground, digital ground, and/or power line. Doing so may damage the board.

Each input accepts 5V TTL signals.

## Difference from AD16-64(LPCI)LA

The functions same with conventional product of AD16-64(LPCI)LA are provided with this product. In addition, as there is compatibility in terms of connector shape and pin assignments, it is easy to migrate from the existing system. So you can use the same operating procedures as AD16-64(LPCI)LA.

There are some differences in specifications as shown below.

	AI-1664LA-LPE	AD16-64(LPCI)LA
Power consumption	+3.3VDC 620 mA (Max.)	+5VDC 450 mA (Max.)
Bus specification	PCI Express Base Specification Rev. 1.0a x1	PCI (32-bit, 33MHz, Universal key shapes supported)
External start signal	LVTTTL-level	TTL-level
External stop signal	LVTTTL-level	TTL-level
External clock signal	LVTTTL-level	TTL-level
Digital Input/Output	LVTTTL-level positive logic	TTL-level positive logic
External Counter Input/Output	LVTTTL-level	TTL-level
Dimension (mm)	121.69 (L)×67.90(H)	121.69(L)×63.41(H)
Weight	90g	60g